

# ANTI VACUUM VALVES

## FIG 568 & FIG 568SS SERIES

**Anti-vacuum valves are normally fitted at the top of the vessel or pipeline being protected.**

Fig. 568 valves are screwed with a BSP taper thread and should be fitted to an appropriate connection. Care should be taken that jointing material does not contaminate the valve seating areas. An anti-vacuum valve should be sized so that its capacity is equal to, or greater, than the rate of vacuum formation in the vessel being protected.

The operation of valves in service should be checked at least every 12 months by removing the dust cover and ensuring that the valve is free to lift off its seat.



# NABIC™

46-48 WILBURY WAY, HITCHIN, HERTFORDSHIRE, SG4 0UD  
 Tel: +44 (0) 1462 443 278 Fax: +44 (0) 1462 443 127  
 E-mail: [nabicsales@cranebsu.com](mailto:nabicsales@cranebsu.com) Web: [www.nabicvalves.com](http://www.nabicvalves.com)

Every effort has been made to ensure that the information contained in this publication is accurate at the time of publishing. NABIC assumes no responsibility or liability for typographical errors or omissions or for any misinterpretation of the information within the publication and reserves the right to change without notice.

N\_FIG568\_1215  
 IOM\_1412\_v3

**CRANE**

BUILDING SERVICES & UTILITIES

[www.cranepsu.com](http://www.cranepsu.com)



View online, on mobile and on tablet  
[www.nabicvalves.com](http://www.nabicvalves.com)